



Disney

43224




WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.





⚠️ AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.
Le jouet contient des petites pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants de moins de 3 ans.

⚠️ ADVERTENCIA: PELIGRO DE ASFIXIA.
Juguete que contiene partes pequeñas y una pelota pequeña.
No recomendado para niños menores de 3 años.






1




2








2x

3








4





5







6







7



8






2x



1x

9







1x



1x


10





1x

11






2x



2x


12





2x


13





2x

14






1x



1x

15






2x



2x


16







1x

17






18





19





2x

20






2x




1x

21

1



2






2x



1x

22

1



2






1x



1x

23





1x

24





1x

25





1x

26





1x



1x

27





1x



1x

28





1x

29






1x



1x


30





1x


31





2x

32








1x


33






34






35





2x

36






1x




2x


37






38






39



40







1x



1x

41




1x



1x

42





1x

43






1x





1x

44







45





46







47





48







49





50





2x




1x



51

1





2







52




53




54






55


1



2



3








1x




2x


56







57







58




59





1x


60






2x

61




1x

62






63





64









Disney

WISH

43224



©Disney

43223

43231



Rebuild
the
world™



